



EXPLODED VIEW

BODY BASE ASSEMBLY


VC9062CV (VK7918NNA.AQZQGSF)




BODY COVER ASSEMBLY



DUST TANK ASSEMBLY



ACCESSORIES



REPLACEMENT PARTS LIST

LOC. NO.	PART NO.	DESCRIPTION	SVC	COMMENT(REMARK)
AANBB1	AAN72937901	Base Assembly,Body	R	
ABCAD1	ABC65852301	Brush Assembly,Dust	R	
ABNBA1	ABN31571101	Cap Assembly	R	
ABNTA1	ABN72915202	Cap Assembly	R	
ACQBM1	ACQ74600401	Cover Assembly,Motor	R	
ACQCB1	ACQ74599727	Cover Assembly,Body	R	
ACVBA1	4901FI3435U	Damper Assembly	R	
ADQBE1	ADQ56691102	Filter Assembly,Exhaust	R	
AECG1	AEC72914711	Guide Assembly,Air	R	
AEMAF1	AEM72909203	Hose Assembly,Flexible	R	
AGBN62	AGB69486501	Nozzle Assembly,Floor	R	
AGRPT1	AGR70487601	Pipe Assembly,Telescopic	R	
AHDBR1	AHD57008811	Reel Assembly	R	
AHJBA1	AHJ31688207	Roller Assembly	R	
AJLTD1	AJL72910816	Tank Assembly,Dust	R	
AJWBA1	AJW72910001	Wheel Assembly	R	
EADCS1	EAD60854001	Harness,Single	R	
EADCS2	EAD56276704	Harness,Single	R	
EAUBA1	EAU41711807	Motor Assembly,AC,Vacuum Cleaner	R	
EAUCM1	6549W1S011N	MOTOR(CIRC),SYNCHRONOUS	R	
EBFCP1	6601FI3149B	SWITCH ASSEMBLY,POWER	R	
EBRBM1	EBR41525310	PCB Assembly,Main	R	
MAMBB1	MAM47356103	Base,Body	R	
MAY000	MAY62393901	Box	R	
MBDBB8	MBD47791102	Bumper,Body	R	
MBDBB9	MBD49522602	Bumper,Body	R	
MBGCB1	MBG62038401	Button,Release	R	
MBGCP1	MBG62038701	Button,Power Switch	R	
MBGCR1	MBG47790801	Button,Cord Reel	R	
MBLTT1	MBL62242802	Cap,Tank	R	
MCDBA1	MCD61842801	Connector,Pin	R	
MCKBE1	MCK62440301	Cover,Exhaust Filter	R	
MCKBW1	MCK62440201	Cover,Wheel	R	
MCKBZ1	MCK47375701	Cover,Motor Housing	R	
MCKBZ2	3550FI1824A	COVER,MOTOR	R	
MCKCA1	MCK62437506	Cover,Decor	R	
MCKCB1	MCK62437401	Cover,Body	R	
MCKCD8	MCK47785201	Cover,Decor	R	
MCKCH1	MCK62438101	Cover,Handle	R	
MCKCS1	MCK62438502	Cover,Body(Sub)	R	
MCKCV1	MCK47357801	Cover,Guide	R	

R : SERVICE PARTS