



# EXPLODED VIEW


## BASE ASSEMBLY, BODY




# COVER ASSEMBLY, BODY












# TANK ASSEMBLY, DUST



# NOZZLE ASSEMBLY, STEAM



# ACCESSORIES



# REPLACEMENT PARTS LIST

## VC9206DT(VK8920SCAQ.ADTQGSF)

LOC. NO.	PART NO.	DESCRIPTION	SVC	COMMENT(REMARK)
AAAAA1	5001FI2084B	Accessory Assembly	R	
AANBB1	AAN72920211	Base Assembly,Body	R	
ABCAD1	ABC31805901	Brush Assembly,Dust	R	
ABNBA1	ABN31571101	Cap Assembly	R	
ABNSA1	ABN37057501	Cap Assembly	R	
ACQBE1	ACQ57029712	Cover Assembly,Exhaust	R	
ACQBM1	ACQ73307903	Cover Assembly,Motor	R	
ACQBM2	ACQ73308803	Cover Assembly,Motor	R	
ACQCB1	ACQ73333413	Cover Assembly,Body	R	
ACQTD1	ACQ73337205	Cover Assembly,Dust	R	
ACVBA1	4901FI3435D	Damper Assembly	R	
ADQBE1	ADQ56691103	Filter Assembly,Exhaust	R	
AEC CG1	AEC72914713	Guide Assembly,Air	R	
AEMAC2	AEM59298904	Hose Assembly,Connector	R	
AEMAF1	AEM55864230	Hose Assembly,Flexible	R	
AGBN63	AGB36646401	Nozzle Assembly,Floor	R	
AGBN64	AGB37054818	Nozzle Assembly,Steam	R	
AGBN66	AGB72912301	Nozzle Assembly,Floor	R	
AGRCP1	AGR57026602	Pipe Assembly,Suction	R	
AGRPT1	AGR56250803	Pipe Assembly,Telescopic	R	
AGUSP1	AGU37059102	Plate Assembly,Bottom	R	
AHDBR1	AHD57008815	Reel Assembly	R	
AHJBA1	AHJ31688206	Roller Assembly	R	
AHJSR1	AHJ33151901	Roller Assembly	R	
AHRBA1	AHR72909101	Shaft Assembly	R	
AJLST1	AJL37059702	Tank Assembly,Water	R	
AJLTD1	AJL72909407	Tank Assembly,Dust	R	
AJWBA1	AJW72909101	Wheel Assembly	R	
AJWNA1	AJW33040001	Wheel Assembly	R	
EADBS1	6631FI3156C	Harness,Single	R	
EADCS1	6631FI3155Q	Harness,Single	R	
EADNS1	EAD50124301	Harness,Single	R	
EADSW1	6631FI3173B	Wire,Jump	R	
EAUBA1	EAU61004901	Motor Assembly,AC,Vacuum Cleaner	R	
EAUCM1	6549W1S011N	Motor, AC Synchronous	R	
EBFBP1	6601FI3501B	Switch,Pressure	R	
EBRAP1	6871FX3136B	PCB Assembly,Sub	R	
EBRBM1	EBR41525319	PCB Assembly,Main	R	
EBRCP2	EBR73322801	PCB Assembly,Sensor	R	

R : SERVICE PARTS

LOC. NO.	PART NO.	DESCRIPTION	SVC	COMMENT(REMARK)
EBRSP1	EBR48965201	PCB Assembly,Sub	R	
FACHK1	AEZ59298308	Knob Assembly	R	
MAMAB1	MAM30548102	Base,Nozzle	R	
MAMBB1	MAM47356102	Base,Body	R	
MAMSB1	MAM42859502	Base,Nozzle	R	
MBDBB8	MBD47791101	Bumper,Body	R	
MBDBB9	MBD49522601	Bumper,Body	R	
MBDSB1	MBD42863602	Bumper,Nozzle	R	
MBGCB1	MBG47384003	Button,Release	R	
MBGCR1	MBG47790805	Button,Cord Reel	R	
MCDBA1	MCD61842801	Connector,Pin	R	
MCKAG1	MCK41951412	Cover,Grip	R	
MCKAT1	MCK41951902	Cover,Terminal	R	
MCKBE1	MCK47376509	Cover,Exhaust Filter	R	
MCKBF1	MCK47790701	Cover,Filter	R	
MCKBL1	MCK41952601	Cover,Lever	R	
MCKBM1	MCK62425401	Cover,Motor	R	
MCKBW1	MCK62068506	Cover,Wheel	R	
MCKBZ1	MCK62425301	Cover,Motor Housing	R	
MCKBZ2	MCK62068901	Cover,Motor Housing	R	
MCKCA1	MCK62076801	Cover,Body(Sub)	R	
MCKCB1	MCK62075807	Cover,Body	R	
MCKCD8	MCK47785201	Cover,Decor	R	
MCKCH1	MCK62077101	Cover,Handle	R	
MCKCM1	MCK62076301	Cover,Front	R	
MCKCR1	MCK62075905	Cover,Rear	R	
MCKCV1	MCK47357801	Cover,Guide	R	
MCKOA1	MCK62076501	Cover,Dust	R	
MCKOS1	MCK62076707	Cover,Decor	R	
MCKPC1	MCK41931902	Cover,Pipe	R	
MCKSC1	MCK42859106	Cover,Nozzle	R	
MCKSD8	MCK42861501	Cover,Decor	R	
MCKSD9	MCK42861601	Cover,Decor	R	
MCKSL1	MCK42861801	Cover,LED	R	
MCKSP1	MCK37324902	Cover,Pipe	R	
MCKSW1	MKC42861901	Window,Viewing	R	
MCKTC1	MCK47375601	Cover,Sensor	R	
MCKTH1	MCK62791302	Cover,Handle	R	
MCQBM1	MCQ62400501	Damper,Motor Mount	R	

R : SERVICE PARTS

LOC. NO.	PART NO.	DESCRIPTION	SVC	COMMENT(REMARK)
MCQBZ1	MCQ62032801	Damper, Motor	R	
MDJBM1	MDJ49523101	Filter, Motor Safety	R	
MDJCM1	MDJ49551601	Filter, Motor Safety	R	
MDJCM2	MDJ63305401	Filter, Motor Safety	R	
MDQCF1	MDQ61906205	Frame, Filter	R	
MDSBA1	MDS49552902	Gasket	R	
MDSBA2	MDS49556117	Gasket	R	
MDSBA3	MDS49556301	Gasket	R	
MDSBA6	MDS61917901	Gasket	R	
MDSBA7	MDS61982301	Gasket	R	
MDSBA8	MDS61903401	Gasket	R	
MDSCA1	MDS61921301	Gasket	R	
MDSCA2	MDS49553002	Gasket	R	
MDSCA3	MDS50028901	Gasket	R	
MDSCA4	MDS49531901	Gasket	R	
MDSCA5	MDS50028902	Gasket	R	
MDSCA6	MDS49556105	Gasket	R	
MDSNA1	MDS50331801	Gasket	R	
MDTCA1	MDT47375501	Gear	R	
MDTCG1	MDT35353701	Gear	R	
MEACA1	MEA47785501	Guide, Air	R	
MEACA2	MEA47358001	Guide, Air	R	
MEASG1	MEA42859702	Guide, Air	R	
MEBAG1	MEB41951702	Handle, Grip	R	
MEBCC1	MEB50027401	Handle, Carrier	R	
MEBCC2	MEB61846101	Handle, Carrier	R	
MEBCH1	MEB61850101	Handle, Grip	R	
MEGBH1	MEG47376201	Holder, Cover	R	
MEGCH1	MEG61864301	Holder, Fixing	R	
MEGSH1	MEG37015603	Holder, Cover	R	
MEKBM1	MEK61842301	Housing, Motor	R	
MFCAR1	MFC41952401	Lever, Release	R	
MFCBR1	MFC47376601	Lever, Release	R	
MFCCR1	MFC61843501	Lever, Release	R	
MFCSL1	MFC37016701	Lever, Release	R	
MFCTL1	MFC47374801	Lever, Release	R	
MFGAC1	MFG41952501	Locker, Connector	R	
MFGCL1	MFG47785805	Locker, Connector	R	
MFVAC1	MFV61841902	Nozzle, Crevice	R	

R : SERVICE PARTS



LOC. NO.	PART NO.	DESCRIPTION	SVC	COMMENT(REMARK)
MFVSN1	MFV42859902	Nozzle,Guide	R	
MFZSP1	MFZ42862701	Packing,Gasket	R	
MGESP1	MGE37026602	Pipe,Suction	R	
MGJTR1	MGJ47375302	Plate,Rotation	R	
MGZBA1	3A00644B	Ring,E	R	
MGZSR1	4352FI4679E	Ring	R	
MGZTR1	MGZ47799901	Ring,Guide	R	
MHJSS1	MHJ37980502	Shaft	R	
MHJSS2	4580FI4589D	Shaft	R	
MHYAC1	MHY37941601	Spring,Coil	R	
MHYBC1	4970FI4230K	Spring,Coil	R	
MHYCA1	4970FI3156D	Spring	R	
MHYCC1	4970FI4230C	Spring,Coil	R	
MHYCC2	4970FI4511Y	Spring,Coil	R	
MHYCC3	4970FI4694K	Spring,Coil	R	
MHYTC1	4970FI4694L	Spring,Coil	R	
MJCTA1	MJC47358301	Strainer,Inner	R	
MJHCM1	MJH47371601	Supporter,Motor	R	
MJHCS1	MJH56778801	Supporter,Lever	R	
MJHHP1	MJH41952701	Supporter,PCB	R	
MJMTB1	4838FI3001A	Tank,Base	R	
MJM TD1	MJM61843101	Tank,Dust	R	

R : SERVICE PARTS

# REPLACEMENT PARTS LIST

## VC9207GR(VK8920SCAQ.ABKQGSF)

LOC. NO.	PART NO.	DESCRIPTION	SVC	COMMENT(REMARK)
AAAAA1	5001FI2084B	Accessory Assembly	R	
AANBB1	AAN72920210	Base Assembly,Body	R	
ABCAD1	ABC31805901	Brush Assembly,Dust	R	
ABNBA1	ABN31571101	Cap Assembly	R	
ABNSA1	ABN37057501	Cap Assembly	R	
ACQBE1	ACQ57029711	Cover Assembly,Exhaust	R	
ACQBM1	ACQ73307903	Cover Assembly,Motor	R	
ACQBM2	ACQ73308803	Cover Assembly,Motor	R	
ACQCB1	ACQ73333412	Cover Assembly,Body	R	
ACQTD1	ACQ73337204	Cover Assembly,Dust	R	
ACVBA1	4901FI3435D	Damper Assembly	R	
ADQBE1	ADQ56691103	Filter Assembly,Exhaust	R	
AECG1	AEC72914713	Guide Assembly,Air	R	
AEMAC2	AEM59298904	Hose Assembly,Connector	R	
AEMAF1	AEM55864229	Hose Assembly,Flexible	R	
AGBN63	AGB36646401	Nozzle Assembly,Floor	R	
AGBN64	AGB37054817	Nozzle Assembly,Steam	R	
AGBN66	AGB72912301	Nozzle Assembly,Floor	R	
AGRCP1	AGR57026602	Pipe Assembly,Suction	R	
AGRPT1	AGR56250803	Pipe Assembly,Telescopic	R	
AGUSP1	AGU37059102	Plate Assembly,Bottom	R	
AHDBR1	AHD57008815	Reel Assembly	R	
AHJBA1	AHJ31688206	Roller Assembly	R	
AHJSR1	AHJ33151901	Roller Assembly	R	
AHRBA1	AHR72909101	Shaft Assembly	R	
AJLST1	AJL37059702	Tank Assembly,Water	R	
AJLTD1	AJL72909408	Tank Assembly,Dust	R	
AJWBA1	AJW72909101	Wheel Assembly	R	
AJWNA1	AJW33040001	Wheel Assembly	R	
EADBS1	6631FI3156C	Harness,Single	R	
EADCS1	6631FI3155Q	Harness,Single	R	
EADNS1	EAD50124301	Harness,Single	R	
EADSW1	6631FI3173B	Wire,Jump	R	
EAUBA1	EAU61004901	Motor Assembly,AC,Vacuum Cleaner	R	
EAUCM1	6549W1S011N	Motor, AC Synchronous	R	
EBFBP1	6601FI3501B	Switch,Pressure	R	
EBRAP1	6871FX3136B	PCB Assembly,Sub	R	
EBRBM1	EBR41525319	PCB Assembly,Main	R	
EBRCP2	EBR73322801	PCB Assembly,Sensor	R	

R : SERVICE PARTS

LOC. NO.	PART NO.	DESCRIPTION	SVC	COMMENT(REMARK)
EBRSP1	EBR48965201	PCB Assembly,Sub	R	
FACHK1	AEZ59298308	Knob Assembly	R	
MAMAB1	MAM30548102	Base,Nozzle	R	
MAMBB1	MAM47356102	Base,Body	R	
MAMSB1	MAM42859502	Base,Nozzle	R	
MBDBB8	MBD47791101	Bumper,Body	R	
MBDBB9	MBD49522601	Bumper,Body	R	
MBDSB1	MBD42863602	Bumper,Nozzle	R	
MBGCB1	MBG47384003	Button,Release	R	
MBGCR1	MBG47790805	Button,Cord Reel	R	
MCDBA1	MCD61842801	Connector,Pin	R	
MCKAG1	MCK41951411	Cover,Grip	R	
MCKAT1	MCK41951902	Cover,Terminal	R	
MCKBE1	MCK47376508	Cover,Exhaust Filter	R	
MCKBF1	MCK47790701	Cover,Filter	R	
MCKBL1	MCK41952601	Cover,Lever	R	
MCKBM1	MCK62425401	Cover,Motor	R	
MCKBW1	MCK62068505	Cover,Wheel	R	
MCKBZ1	MCK62425301	Cover,Motor Housing	R	
MCKBZ2	MCK62068901	Cover,Motor Housing	R	
MCKCA1	MCK62076801	Cover,Body(Sub)	R	
MCKCB1	MCK62075805	Cover,Body	R	
MCKCD8	MCK47785201	Cover,Decor	R	
MCKCH1	MCK62077103	Cover,Handle	R	
MCKCM1	MCK62076301	Cover,Front	R	
MCKCR1	MCK62075904	Cover,Rear	R	
MCKCV1	MCK47357801	Cover,Guide	R	
MCKOA1	MCK62076501	Cover,Dust	R	
MCKOS1	MCK62076705	Cover,Decor	R	
MCKPC1	MCK41931902	Cover,Pipe	R	
MCKSC1	MCK42859107	Cover,Nozzle	R	
MCKSD8	MCK42861501	Cover,Decor	R	
MCKSD9	MCK42861601	Cover,Decor	R	
MCKSL1	MCK42861801	Cover,LED	R	
MCKSP1	MCK37324902	Cover,Pipe	R	
MCKSW1	MKC42861901	Window,Viewing	R	
MCKTC1	MCK47375601	Cover,Sensor	R	
MCKTH1	MCK62791305	Cover,Handle	R	
MCQBM1	MCQ62400501	Damper,Motor Mount	R	

R : SERVICE PARTS

LOC. NO.	PART NO.	DESCRIPTION	SVC	COMMENT(REMARK)
MCQBZ1	MCQ62032801	Damper, Motor	R	
MDJBM1	MDJ49523101	Filter, Motor Safety	R	
MDJCM1	MDJ49551601	Filter, Motor Safety	R	
MDJCM2	MDJ63305401	Filter, Motor Safety	R	
MDQCF1	MDQ61906205	Frame, Filter	R	
MDSBA1	MDS49552902	Gasket	R	
MDSBA2	MDS49556117	Gasket	R	
MDSBA3	MDS49556301	Gasket	R	
MDSBA6	MDS61917901	Gasket	R	
MDSBA7	MDS61982301	Gasket	R	
MDSBA8	MDS61903401	Gasket	R	
MDSCA1	MDS61921301	Gasket	R	
MDSCA2	MDS49553002	Gasket	R	
MDSCA3	MDS50028901	Gasket	R	
MDSCA4	MDS49531901	Gasket	R	
MDSCA5	MDS50028902	Gasket	R	
MDSCA6	MDS49556105	Gasket	R	
MDSNA1	MDS50331801	Gasket	R	
MDTCA1	MDT47375501	Gear	R	
MDTCG1	MDT35353701	Gear	R	
MEACA1	MEA47785501	Guide, Air	R	
MEACA2	MEA47358001	Guide, Air	R	
MEASG1	MEA42859702	Guide, Air	R	
MEBAG1	MEB41951702	Handle, Grip	R	
MEBCC1	MEB50027401	Handle, Carrier	R	
MEBCC2	MEB61846101	Handle, Carrier	R	
MEBCH1	MEB61850104	Handle, Grip	R	
MEGBH1	MEG47376201	Holder, Cover	R	
MEGCH1	MEG61864301	Holder, Fixing	R	
MEGSH1	MEG37015603	Holder, Cover	R	
MEKBM1	MEK61842301	Housing, Motor	R	
MFCAR1	MFC41952401	Lever, Release	R	
MFCBR1	MFC47376601	Lever, Release	R	
MFCCR1	MFC61843501	Lever, Release	R	
MFCSL1	MFC37016701	Lever, Release	R	
MFCTL1	MFC47374804	Lever, Release	R	
MFGAC1	MFG41952501	Locker, Connector	R	
MFGCL1	MFG47785805	Locker, Connector	R	
MFVAC1	MFV61841902	Nozzle, Crevice	R	

R : SERVICE PARTS

LOC. NO.	PART NO.	DESCRIPTION	SVC	COMMENT(REMARK)
MFVSN1	MFV42859902	Nozzle,Guide	R	
MFZSP1	MFZ42862701	Packing,Gasket	R	
MGESP1	MGE37026602	Pipe,Suction	R	
MGJTR1	MGJ47375302	Plate,Rotation	R	
MGZBA1	3A00644B	Ring,E	R	
MGZSR1	4352FI4679E	Ring	R	
MGZTR1	MGZ47799901	Ring,Guide	R	
MHJSS1	MHJ37980502	Shaft	R	
MHJSS2	4580FI4589D	Shaft	R	
MHYAC1	MHY37941601	Spring,Coil	R	
MHYBC1	4970FI4230K	Spring,Coil	R	
MHYCA1	4970FI3156D	Spring	R	
MHYCC1	4970FI4230C	Spring,Coil	R	
MHYCC2	4970FI4511Y	Spring,Coil	R	
MHYCC3	4970FI4694K	Spring,Coil	R	
MHYTC1	4970FI4694L	Spring,Coil	R	
MJCTA1	MJC47358301	Strainer,Inner	R	
MJHCM1	MJH47371601	Supporter,Motor	R	
MJHCS1	MJH56778801	Supporter,Lever	R	
MJHHP1	MJH41952701	Supporter,PCB	R	
MJMTB1	4838FI3001A	Tank,Base	R	
MJM TD1	MJM61843101	Tank,Dust	R	

R : SERVICE PARTS